

F: 1.450.500.0021 Toll Free: 1 877 287.7777

Inflotrolix Inc.

INSTALLATION AND REMOVAL INSTRUCTIONS

FOR AQUA-PROTEC & RPSM

PROJECT	AP-01 – BL-01
SPECIFICATION	N/A
COMPONENT	AQUA-PROTEC & RPSM
BCS PART NUMBER	AP-01, BL-01
CUSTOMER COMPONENT NUMBER	N/A
SAMPLE	N/A

	Name / Title	Signature	Date (YY/mm/dd)
Prepared by:	Patrick Savaria		
Approved by:	Sylvain Santerre, Eng.		

Date of 1st revision (YYYY/mm/dd)	2009-05-01	Revision number:	А
Last revision date: (YYYY/mm/dd)	2014-05-08		G

This document and its contents are the property of Inflotrolix inc. and of its subsidiaries. This document contains confidential information. The reproduction, distribution and use of this document in its entirety or in part without written authorization are prohibited. The offenders will be responsible of any and all damages.



INFLOTROLIX INC. C6-3275, Chemin de l'Industrie St-Mathieu de Beloeil QC, J3G 0M8, Canada T : 450 445.0700 F : 1.450.500.0021 Toll Free: 1 877 287.7777

Revision List

Revision number	Date (YY/mm/dd)	Description
Α	2009-06-01	Release of document
В	2010-08-15	Major change of the control panel
С	2011-01-15	Change in installation procedures
D	2011-12-05	Change in installation procedures
Е	2012-03-01	Change in installation procedures
F	2013-05-23	Security seal and RPSM
G	2014-05-08	Cable tie, anchor ring, typical installation drawings



F: 1.450.500.0021 Toll Free: 1 877 287.7777

Table of Contents

1.	GENERALPag	ge 4
2.	TYPICAL INSTALLATION DRAWINGSPa	ge 4
3.	CONTENTS OF AQUA-PROTEC SYSTEMPa	ge 6
4.	REQUIRED TOOLS & EQUIPMENTPa	ge 9
5.	INSTALLATION AND REMOVAL OF THE RPSMPage	e 10
	5.1 Preparation of Clean-Out for Insertion and measurement taking	
	5.2 Pre-Installation assembly	
	5.3 Insertion and positioning	
	5.4 Removal of the RPSM	
6.	SAFETY CONSIDERATIONSPage	e 18



F: 1.450.500.0021 Toll Free: 1 877 287.7777

1- GENERAL

This document contains the instructions for installing and removing the Aqua-Protec (AP-01) and the Retractable Pneumatic Sealing Module (RPSM) (BL-01 used as example and referred to as bladder). This document is intended for "Inflotrolix Certified" plumbers & technicians. The configuration instructions for the Aqua-Protec control panel are contained in a separate document. This document is exclusively intended for plumbing & control industry professionals.

2- TYPICAL INSTALLATION DRAWINGS




Figure 1: Typical installation




Figure 2: Typical installation –Cables used to extract the bladder limit the installation depth to 4ft. To limit presence of detergent suds we recommend sensors to be 10x pipe diameter away from plumbing stack.



F : 1.450.500.0021 Toll Free: 1 877 287.7777




Figure 3: Not recommended installation




Figure 4: System will NOT protect plumbing fixtures located below that point (e.g.: floor drain, shower drain, toilet, etc.).



F: 1.450.500.0021 Toll Free: 1 877 287.7777

3- CONTENTS OF AQUA-PROTEC SYSTEM

QTY DESCRIPTION IMAGE

1 Aqua-Protec (AP-01)

- Retractable Pneumatic Sealing
 Module (RPSM) (BL-01)
 Referred to as bladder in the manual
- 1 Installation rod 5ft (TI-01) or 2ft (TI-02) and sizing tool
- 1 Universal clean-out cover (CU-01)
- 1 Universal clean-out cover O-ring (large one)
- 1 Anchoring ring (AA-01)





F : 1.450.500.0021 Toll Free: 1 877 287.7777

- 1 Anchoring ring seal
- 1 Cable gland
- 1 Cable gland O-ring (small one)
- 1 Cable gland nut
- 1 double snap grip clamp
- 1 Cable tie
- 1 Compression ring (cast iron)
- 2 Hex bolts (cast iron)









F: 1.450.500.0021 Toll Free: 1 877 287.7777

- 2 Washers (cast iron)
- 1 Stainless Steel hex screw
- Aqua-Protec Non-petrolium based lubriciant vial
- 1 Aqua-Protec security seal

- 1 User manual
- 1 Warranty (AP-01 and BL-01)



User Manual

Inflotrolix






F: 1.450.500.0021 Toll Free: 1 877 287.7777

4- REQUIRED TOOLS & EQUIPMENT

- Gloves
- Installation tool (GI-01)
- Nylon pipe brush and steel pipe brush
- Marker
- Cutting tool
- Cable ties
- Hex head screwdriver (5/16")
- Camera (optional)
- Ratchet with ½ inch box (cast iron install)





F: 1.450.500.0021 Toll Free: 1 877 287.7777

5- INSTALLATION AND REMOVAL OF THE RPSM

5.1 Preparation of Clean-Out for Insertion and the measurement taking

STEP DESCRIPTION ILLUSTRATION

Remove existing cover from the clean-out.


Use a flexible pipe brush to clean and remove debris from clean-out assembly.

Attach the Installation tool (GI-01) on the Installation rod (TI-01). Sizing tool should be screwed onto receiving end of the installation rod; the assembly should be fingertight.

Position yourself facing the municipal-side of the main sewer pipe.




Insert the Installation rod until the sizing tool snaps into place





F: 1.450.500.0021 Toll Free: 1 877 287.7777

With a felt marker, draw a reference mark on the Installation rod flush with the bottom of the threads.



Twist the Installation rod 180°, and then slowly pull the sizing tool out of the clean-out assembly.

5.2 Pre-Installation Assembly

STEP DESCRIPTION ILLUSTRATION

5.2.1 Remove the control panel (AP-01) of its packaging.



Take the Universal clean-out cover (CU-01) and bladder out of its packaging.







F: 1.450.500.0021 Toll Free: 1 877 287.7777

STEP DESCRIPTION ILLUSTRATION

Take the Anchoring ring (AA-01)
and seals out from packaging. Seal to be installed only for cast iron installation.







5.2.4 Depending of the type of pipe, install the cable gland on the correct side of the Universal clean-out cover (CU-01). Do not forget to install the seal on the cable gland first. (left photo: ABS; right photo: cast iron)





Insert the end of the umbilical cable
5.2.5 through the Universal clean-out
cover (CU-01) and the cable gland.
The main part of cable gland
should always be on the exterior
side of the clean-out.





Use a cable tie to double secure the connection.





5.2.7



F: 1.450.500.0021 Toll Free: 1 877 287.7777

STEP DESCRIPTION ILLUSTRATION

5.2.8 Connect the air hose of the umbilical cable to the barb fitting on the bladder. Use the double snap grip clamp to secure the air hose in place.





5.2.9 Attach Installation rod to the bladder bolt-on swivel (finger tight).



Secure tip of the rod with the hex 5.2.10 screw aligned with top of anchoring ring





5.2.11 The pre-installation assembly should look like this.





F: 1.450.500.0021 Toll Free: 1 877 287.7777

5.3 Insertion and positioning

STEP DESCRIPTION ILLUSTRATION

5.3.1 Open the panel with a flathead screwdriver.



5.3.2 Plug the AC adapter into an electrical outlet.



In the panel, connect the 3 pin battery connector to the PCB.



Using a metallic tool, make a connection between the 3
5.3.4 water sensors. The yellow light on panel should light up when touching the sensors.





5.3.5 Apply lubricant on the bladder.

Lubricant needs to be applied all the way around the top part of the bladder.





5.3.6

5.3.9

INFLOTROLIX INC. C6-3275, Chemin de l'Industrie St-Mathieu de Beloeil QC, J3G 0M8, Canada T : 450 445.0700

F: 1.450.500.0021 Toll Free: 1 877 287.7777

Apply Aqua-Protec lubricant on the middle part of the sole of the bladder. Then apply some more on the bottom part of the sole.





Insert bladder into the clean-out assembly facing the municipal - side of the sewer pipe.

5.3.8 Insert and properly position the bladder inside the wye pushing the rod and keeping the extraction cables taut.



Position the Anchoring ring so that it rests securely on the bottom lip of the threaded section of the cleanout entry.

Attach the extraction cables to the Anchoring ring with a cable tie.



5.3.10 Hands tighten the Universal Cleanout cap in place and tighten the cable gland to insure water tightness.



For a cast iron installation, install the compression ring on top of the Universal Cleanout cap.





F : 1.450.500.0021 Toll Free: 1 877 287.7777

Tighten the compression ring 5.3.12 with the 2 HEX bolts and washers contained in the bag



5.3.13 Apply the security seal



5.3.14 The assembly should be positioned as such.



5.3.15 Using the Configuration Manual, proceed with Aqua-Protec system configuration



F: 1.450.500.0021 Toll Free: 1 877 287.7777

5.4 Removal of the bladder

STEP DESCRIPTION ILLUSTRATION

Shut-down the control panel.

5.4.1 (See shut-down procedure from Configuration manual)



- 5.4.2 Loosen the cable gland
- Loosen and remove the
 Universal cleanout cap from the clean-out.



Keeping the anchor ring attached, carefully pull on the Installation rod and the extraction cables until the bladder is retracted out of the clean-out. Lubricate as required.







Toll Free: 1 877 287.7777

6- SAFETY CONSIDERATIONS

It is important that the installer ensures that the Aqua-Protec is safely installed for users. Particular attention should be paid to the anchoring of the control panel on the wall and of the passage of the umbilical cord. This cable should be anchored to prevent anyone from tripping and get hooked, which could result in injury or system damage. Ideally, the cable will be installed under the floor and concealed in the walls so that no one can trip on it.