



Quick Mobile App Guide

Menu Button

Le's you navigate through the menus such as settings, history, users and more

System Status

This indicates the system status to indicate if the system can be armed and if it is alarmed.

Error Message

This indicates the reason of alarm or of trouble such as supervision fault or low battery. If no troubles are detected, it will be written Everything is ok.

Devices Controls

Those buttons bring you to the control page of the specific device type while the home icon brings you back to the overview.

Lights and motors

Thermostats

□ Cameras

Door locks

((e)) Sensors



www.nowasupport.com

Security Functions

Let's you arm away, arm stay and disarmed. Those functions are **ONLY USED** for security system usage.

System Armed Status

This indicates if the system is armed or not. Even if the system is "Disarmed" the Nowa water leak protection always works

Navigate Through Areas

Tap on the arrow to go to the next area of your system (Ex: Nowa 360, Security, Motion)

Nowa Valve Control

These buttons are used to control the Nowa valve. The reset button, will cancel the leak alarm if no water is detected. Once the alarm is cancelled you can use "Open valve" and "Close valve" to control it.

nowa360.com