

How to manually open the Nowa valve

Context

During a power failure, the Nowa 360 system will still operate on the backup battery. When the battery charge is depleted, the system will shut down and the valve will close on it's own to protect the customer.

If the power failure continues and you need water, you still have the option to manually open the valve with the white knob located on the black actuator (**see yellow circle below**). Using the manual override bypass the normal behavior of the Nowa 360 system.

Manual Override

1. Go to the valve location
2. Locate the white knob on the top of the black actuator
3. Pull the white knob from the actuator
4. Start turning the white knob clockwise until the red line is parallel to the water pipe.
**You may need to redo this step until the power inside the valve is depleted.*
5. Keep the white knob lifted from the actuator for the duration of the power outage



When the electricity is restored, you must push back the white knob against the actuator and make sure the system is working

You can test it by opening / closing the valve through the mobile app or the physical buttons on the control unit

